



## 1040-900 AUSTART SERVICE KIT

Item No.	Part ID	Description	Qty
5	1005-000	O'ring	1
6	1006-000	Circlip	1
7	1007-000	Seal	1
10	1010-000	O'ring	1
12	1012-000	Cup Seal	1
14	1014-000	O'ring	1
15	1015-000	O'ring	1
18	1018-000	O'ring	1

Note: If kit is used to service an Austart RS1000M Relay Valve, Item No. 12 (1012-000) cup seal is not used.

